

Deflating & Storing Challenge Course



Step One:



Detach air pump and un-zip the air holes.

Step Two:



Place the inflatable as flat as possible. Fold in outside walls on the base of the inflatable. Leaving the base of the inflatable as the edge.

Step Three:



Volunteers roll along the inflatable to ensure all air is let out.

**Roll toward air tubes*

Step Four:



Fold the two fourths in – one on top of the other.

Step Five:



Tightly roll the inflatable toward the air holes. Fold in air tubes.

Step Five:



Secure the inflatable with straps

Deflating & Storing Bounce House

Step One:



Place the inflatable as flat as possible. Fold in outside walls on the base of the inflatable. Leaving the base of the inflatable as the edge

Step Two:



Fold in one-fourth from both sides.

**Prior to folding, make sure at least one of the air tubes is able to let more air out during the rolling process.*

Step Three:



Volunteers roll along the folded inflatable to ensure all air is let out.

**Roll toward air tubes*

Step Four:



Fold the two fourths in – one on top of the other.

Step Five:



Tightly roll the inflatable toward the air holes. Fold in air tubes.

Step Five:



Secure the inflatable with straps and store in bag.